

Software Activation Procedure for PHE DESIGNER

Software Version:

4.19.16 PHE-Designer P4 L

To download and enable the gasketed plate heat exchanger sizing software, please follow the steps below:

1. Remove the previous version of the software (if you have already installed a previous version on your PC).
2. Please go to the Reserved area of the Fiorini Website: http://www.fiorini-industries.com and download the new release of the software from “Software PHE” folder.
3. Unzip the folder
4. Open the file phe-designer-OPS.exe.
5. A window like the following will now display:



6. Take note of the “Computer ID”
7. Fill out the form at this LINK (mandatory for receiving the code).
8. You will receive the activation code via email, which should be entered in the "Activation Code" field.

Note: In some versions of Windows, opening the file may trigger a security alert because the file is not recognized as safe. In this case, a window like the following may appear:

You need to click on "More info" first; on the next screen, click on "Run anyway," and then proceed with the installation.





